

## SURVEYING GUIDE

- Eaves to sit flush on the external upstand.
- Ensure upstand is level and square.
- It is the responsibility of the installer to determine the finishing detail of the inside.



Download the installation guide at [www.korniche.co.uk](http://www.korniche.co.uk)

